

MORGAN TOOL BOX FITTING INSTRUCTIONS

Firstly make sure you have at least 570 mm of clear width at the lower rear attachment of the spare wheel shield: cars with integral lights in the rear valance will NOT have this much.

Remove the shield and shorten as per the pic, bottom flange and about 100 mm / 4 inches up.

Replace shield



You will now see the 3 holes in the chassis rail that the tool box is going to sit on and be bolted to.

Put tool box in position, normally equal distance either side of the car's centre line / equal distance side to side

NB: the box rest on the chassis and the flange lip rests on the rear most wood strut.



Mark the holes on the bottom of the box from underneath, remove box and drill holes, deburr.

Attach box to the chassis with bolts provided.

Place rubber mat in bottom of box

Place seal round the top edge, place lid on top and secure with elastic strap.

