



USING A HOLE CUTTER AS ILLUSTRATED
IN Pic 1
MARK THE DIAMETER AND EXPAND THE
HOLE IN THE BRACKET TO 16 dia. Pic 2

TURN THE ECCENTRIC BUSH TO THE 12 o'clock
POSITION TO GIVE AS MUCH 'HEIGHT' AND
JOINT CLEARANCE AS POSSIBLE. Pic 3

FOR THE ATTACHMENT TO THE ANTIROLL
BAR, THE JOINT GOES ONTO THE LOWER
SURFACE OF THE BAR AND THE TOP HAT BUSH
ON TOP.

HOLD THE BALL JOINT STUDS WITH A HEX KEY
AND TIGHTEN UP ALL FIXINGS.

