

## TR BALL JOINTED ANTI ROLL BAR LINKS - FITTING INSTRUCTIONS

- Follow recognised safe working practices when working on the car.
- Refer to a recognised workshop manual if necessary.
- Remove the old antiroll bar links.
- Attach the right angled end of the link to the wishbone bracket, tighten nut.
- Attach the lower joint to the antiroll bar, tighten nut
- Road test and recheck all attachments for correct tightness.

